

# Options and Accessories

# Refrigerant condensers

# **Options and Accessories**

Below is a listing of the main Polairis™ options and accessories. If your required option or accessory is not listed, look no further than your <u>local BAC representative</u>.



#### Sound attenuation

Reducing noise at air intake and discharge points brings us closer to silent cooling equipment.



#### **Remote sump connection**

The best way to **prevent a sump freezing** is to use the auxiliary remote variety within a heated area. Shutting off the circulating pump allows all the water in the water distribution, as well as that in suspension and the sump to drain freely to the auxiliary sump.





## Basin heater package

Thanks to our factory-installed heaters, the water stays at 4°C and **never freezes**, even during equipments downtime and however cold it gets outside.



#### **Platforms**

To inspect and maintain from the top of the unit more **easily** and **safely**, platforms can be installed.



# Ladder, safety cage and handrail

A ladder, safety cage and handrails **all facilitate access to the top of the unit** and safe inspection of your condenser.





## Discharge hood

Discharge hoods **reduce the risk of re-circulation** in tight enclosures by increasing discharge air velocity, and can be used to elevate the unit discharge above adjacent walls to comply with layout guidelines.



# **Flanges**

Flanges facilitate piping connections on-site.



### Water treatment equipment

Devices to control water treatment are needed to ensure proper **condenser water care**. Not only does this help protect the components, controlling corrosion, scaling and fouling, it also avoids the proliferation of harmful bacteria, including **legionella**, in the recirculating water.





#### **Filter**

Separators and media filters efficiently **remove suspended solids** in the recirculating water, reducing system cleaning costs and optimizing water treatment results. Filtration helps you keep the recirculating water clean.



## Clean out port

Clean out port makes it easy to eliminate silt and sludge from the condenser basin when cleaning and flushing the sump.